



1.6 16V (EA0B,EA04,EA11) (03/1999 - 09/2003)
2.0 16V (EA03,EA0P,EA14) 11/1999-09/2003



01163



01174
SMI



01174
SMI



01164



01163



01162
TRW



01162
TRW



01164



01066



01068



01067



01137



01137

