



1.4 (LA0E,LA0V) (09/1996-08/2003)

1.4 16V (LA0D,LA1H,LA10) (03/1999-08/2003)

1.6E (LA0F) (LA0S) (09/1996-03/1999)

1.6i (LA0L) (09/1996-03/1999)

1.9D (LA0A,LA0U) (02/2001-08/2003)

2.0i (LA07,LA0G) (09/1996-08/2003)



01166



01165
SMI



01165
SMI



01167



01166



01200
TRW



01200
TRW



01167



01066



01068



01067



01137



01137

